


Z-Backlighter Laser Facility Z-Beamlet and Z-Petawatt Laser Systems

A shot on the Z Machine



International Conference on Ultrahigh Intensity
Lasers

Shanghai-Tongli, China, October 27-31 2008

Briggs Atherton, Sandia National Laboratories

(505) 284-9505; bwather@sandia.gov



Z-Backlighter-Team Members

Manager

Briggs Atherton

Laser Science and Operations

Richard Adams
Dave Bliss
Verle Bigman
Mark Kimmel
Patrick Rambo
Jens Schwarz
Jon Shores
Ian Smith

Electronics, Controls and Pulsed Power

Robin Broyles
Jeff Georgeson
Drew Johnson
Randy Manzanares
Tracy Montoya
Kathleen Pettit
Allen Smith

Target Science and Experiments

Guy Bennett
Aaron Edens
Matthias Geissel

Optics and Cleanroom Support



John Bellum
Damon Kletecka
Wade Nead
James Potter
Joanne Wistor

Engineering

Daniel Headley
Jeff Kellogg
Marc Ramsey
Grafton Roberson



The new ZR facility in operations




Capability	Z	ZR
Peak load current reproducibility	5%	2%
Pulse shaping flexibility	Minimal	Significant Variability
Peak Current	18 MA	26 MA
Full current operation	100 ns	130ns, 300ns
Diagnostic Lines of Sights	9	18




Sandia's ZR z-pinch facility

Phases of a z-pinch implosion


initiation




implosion





stagnation



ZR z-pinch facility



wire array



ZR parameters

- 20 MJ stored energy
- 26 MA peak current
- 100 TW electrical power pulse
- ≥ 300 TW x-ray power
- ≥ 2 MJ x-ray energy
- ≥ 200eV Blackbody radiation





The Z-Backlighter Laser facility

Z facility


- The terawatt-class Z-Beamlet laser creates backlighting x-ray sources in the 1-9 keV range.
- The Z-Petawatt laser creates backlighting > 8keV range

Final Optics Assembly Installed on Z

laser building




Z-Backlighter laser facility






Point projection x-ray backlighting using the Z-Beamlet Laser



Z-Beamlet Laser




L. E. Ruggles, a) et. al.
 REVIEW OF SCIENTIFIC INSTRUMENTS VOLUME 74, NUMBER 3 MARCH 2003






Point-projection x-ray backlighting has been used extensively to study ICF capsule implosions

Initial 6.7 keV imaging used a 4.8x imaging geometry with a large laser focal spot size


Improved 6.7 keV system used 1.7x imaging with 100 μm spot sizes to yield 50 μm spatial resolution



Nov-Dec 2001 [4.8x, 3.2 m lens, 25 cm x 25 cm aperture]




May-June 2002 [1.69x, 2 m lens, 34 cm x 34 cm aperture]






Curved-crystal imaging offers an elegant solution for backlighting in hostile environments



Bent-crystal Imaging

- Monochromatic (~0.5 eV bandpass)
- 10 micron resolution
- Large field of view (e.g. 20 mm x 4 mm)
- Debris mitigation






- Concept proposed in mid-1990s.
 - S.A. Pikuz *et al.*, *Rev. Sci. Instrum.* **68**, 740 (1997).
- A 1.865 keV backlighter built at NRL
 - Y. Aglitskiy *et al.*, *Rev. Sci. Instrum.* **70**, 530 (1999).
- Crystal imaging techniques proposed for microscopy/backlighting on NIF
 - J.A. Koch *et al.*, *Rev. Sci. Instrum.* **70**, 525 (1999).
- 1.865 and 6.151 keV diagnostics successfully implemented on Z facility
 - D.B. Sinars *et al.*, *Rev. Sci. Instrum.* **75**, 3672 (2004).



The higher spatial resolution bent-crystal imaging system revealed new features in imploding capsules

3.4-mm diameter plastic ICF capsule

Capsules had 100s of known defects on surface that apparently produced a myriad of small jets





Available Laser Systems

Z Backlighter

Z Beamlet

- $\lambda=527\text{nm}$
- $\tau=0.3\text{-}8\text{ns}$
(2ns common)
- $\phi\sim 75\mu\text{m}$ spotsize
- $E<2\text{kJ}$
- $I<10^{17}\text{ W/cm}^2$
- $\sim 3\text{ hr/shot}$
- 2 pulse MFB

Z Petawatt

- $\lambda=1054\text{nm}$
- $\tau=500\text{fs min}$
- $\phi\sim 30\mu\text{m}$ spotsize
- $E<60\text{J}$ (<500J pending)
- $I>10^{19}\text{ W/cm}^2$
- $\sim 3\text{ hr/shot}$
- Sub-ps probe
@ 527nm, <20mJ

NLS

- $\lambda=1064\text{nm}$ (532nm option)
- $\tau=150\text{ps}$
- $\phi\sim 5\mu\text{m}$ spotsize
- $E<10\text{J}$
- $I<10^{17}\text{ W/cm}^2$
- $\sim 20\text{ min/shot}$
- Pending: 8-10ns operations
at $>100\text{J}$ @ 1ω



Large Scale Coating Chamber



• Recent coating efforts have focused on Z-Petawatt needs, including 94 cm truncated HR mirrors.



<i>FY07 Optics</i>	<i>30 cm</i>	<i>60 cm</i>	<i>94 cm</i>
<i>Z-Beamlet</i>	42 AR	4AR	
<i>Z-Petawatt</i>	6AR & 4HR	3AR	3HR

- Backlighting operations require a continuous supply of AR coated debris shields.
- To this end, we installed a 90" e-beam deposition coating chamber.
- Single-run capability: 3 at 94 cm optics
 1 at 1.5 m option
- Ion-assisted deposition (IAD) optional





Large Scale Coating Chamber




- Independent damage testing (SPICA) has shown good test results. Using a definition of 25 cumulated damage sites (non-propagating) gives thresholds:
 - In the range of 17-25 J/cm² for AR coatings
 - In the range of 75-85 J/cm² for HR coatings
- Successful application to both air and vacuum use environments.

* 1064nm, 3.5ns pulse, 1.06mm spot scanned to fill 1cm² with 2300 shots for each of 13 levels from 1-37 J/cm², NP sites are of size 15µm





The Z-Beamlet Laser system





The Z-Beamlet Laser has recently being modified to provide a “2-frame” backlighting capability


Injection Box with 10' trombone addition



- Front End**
- The front end beam is split into two variable energy ratios beams $< 10^{16}\text{ W/cm}^2$ per shot
 - 1st beam
 - The focus is changed
 - 2nd beam
 - delayed 2-20 ns
 - Small change in angle (1.3 mrad)




The 100TW/Petawatt System



Patrick Rambo 9:14am Wednesday





The 100TW/Petawatt System






Adaptive Optics

- For higher order corrections, a commercial Phasics adaptive optics system has been installed in August 2007.




- This screen shot shows a compensated full system shot:
PV: 1.03 waves
RMS: 0.07 waves
Strehl ratio: 0.85.





The 100TW/Petawatt System

<500 J every 3 hours (if full-aperture)
<50J every 3 hours (if sub-aperture)








PEPC for Backreflection Isolation

- Initial tests on 100 TW system showed that target back reflection would cause laser damage at 1 PW level.

Polarizer => Installation of plasma electrode Pockels cell for isolation




pepc





The 100TW/Petawatt System






Transport Telescope





The 100TW/Petawatt System





Petawatt Compressor Vessel

Three sections form vessel:

4.4 x 4.4 x 13.2 m³

- 2 Tier design
- weight: 43 tons
- 4600m³/h roughing + 3 ISO 500

Cryos allow:

1x10⁻⁵ Torr in 3 hours or

2x10⁻⁷ Torr in 15 hours

Uncompressed energy: 420 J


Compression: < 2ps

Compressed energy: 225 J







The 100TW/Petawatt System






1st Z-Petawatt Shot (Spectrum)




- Intensities don't scale (different scanning parameters).
- Signal-to-noise ratio for the Z-Petawatt shot is the best we have ever achieved for K_{α} measurements.
- Very nice resolution/separation of $K_{\alpha 1}/K_{\alpha 2}$ doublet.





PW FOA Debris

- Debris is generated from laser target interactions (minor) and z-pinch (major) sources.
 - Vapor debris <25km/s
 - Particulate debris <1km/s
- Terawatt/nanosecond scale backlighting deals debris via debris shields (30X30X1cm³)



Used debris shield

- Petawatt/picosecond scale backlighting must deal with debris differently due to B-integral effects:
 - Thin (2.7 μm) polymer film shields (passive)
 - Intelligent optics enclosure design
 - Fast debris shutters (active)




Target s
• Forces of
optics to r
• Possibly
against la



PW Target Area


• Experimental Capabilities:

- ZBL only
- Z-PW only
- ZBL and Z-PW
- Small pulsed power supply
- High grade radiation shielding





The 100TW/Petawatt System






100TW Target Area

Lasers:

- Typical: 1054 nm, 50 J, < 1 ps, $\sim 10^{19}$ W/cm²
laser intensity pointing stability < 50 μ m
- Optical probe beam at 1054/527 nm, 30/10 mJ,
 τ < 500 fs, ps to multi ns delay possible

Diagnostics:




- $K\alpha$ imager, X-ray pin-hole cameras
- multiple X-ray and optical streak cameras, 200 fs resolution at 1:40 dynamic range, 5 ps at 1:1000
- various X-ray and optical spectrometers
- single photon counting CCD's
- 12 GHz digital scopes
- Thompson parabola
- HV supplies up to 20 kV
- IP and CR39 detectors
- EMI shielded instrumentation cabinets up to 120 dB





Quadrupole Focusing Experiments

Z-100 TW; $E = 40 \text{ J}$, $I > 5 \times 10^{19} \text{ W/cm}^2$



PRL: "Controlled Transport and Focusing of Laser-Accelerated Protons with Miniature Magnetic Devices", 1 August 2008



Conclusion/Future Upgrades

- Every component of the PW system has been exercised and the commissioning shot last year demonstrated integrated system functionality.
- New PW FOA needs to be assembled and installed for ZPW on Z.
- Several subsystems need to be optimized, e.g.: PEPC, DFM, laser diagnostics
- Dichroic mirror will enable ZBL/ZPW on same shot; focusing needs to be addressed
- PW target chamber in Target Bay will allow ZBL/ZPW experiments (planned FY08/09)
- Upgrade to MLD gratings (80cm X 20cm) will allow 240J@600fs operation in the 100TW target chamber
- Upgrade to MLD gratings (1.2 m x 0.4 m) will safely allow: 4.2 kJ @ 10 ps
94 cm x 40 cm gratings already demonstrated at Osaka, 60 cm x 20 cm for testing in house 1.4 kJ @ 600 fs
- Main cavity redesign to full aperture 4-pass configuration will allow to extract up to 5 kJ long pulse; cavity lenses and transport telescope lenses are on order